

GARMIN

CTU WITH SCREEN
P12534 07/01/2025 Rev A


CLIENT GUIDE

Tools Required (supplied)




Parts


Ⓐ x1



Ⓑ x1




1





UNBOX AND REMOVE UNIT
FROM CARTON

2

IF POWER CABLE IS NOT FITTED FOLLOW THESE STEPS




3



4

ACCESSING SCREEN DATA




USE USB EXTENDER TO
UPDATE AND ACCESS SCREEN

5


ACCESSING LOCKED PRODUCT BOX

USE THE SUPPLIED
KEYS TO UNLOCK
THE LOCK ON THE
FRONT FACE.




6

SLIDE THE FRONT
SECTION OF THE
PRODUCT CASE OUT.




7



REMOVE AND ADD PRODUCT
UNITS TO THE SLOTTED
SECTIONS IN THE BASE.

8



RETURN CASE FRONT AND
LOCK USING THE KEY.