

GARMIN


CRADLE N1&N2

P 11186


SEPT 2019

ASSEMBLY DIAGRAM


Tools Required (Not Supplied)



Parts N1




(A) x1




(B) x2

Parts N2




(C) x1




(B) x2

1

N1




2




1

N2



2



7

8

9

10

11

12

ASSETS PAGE – DELETE BEFORE ISSUING OR PRINTING




(A) x#

(A)

(1)

1

Notes



Do NOT use chemical based cleaning products or abrasive cloth's & sponges



Only use soapy warm water and a soft cotton cloth when cleaning the display

