


GARMIN

MID UNITS 1200 ADJOINING
BACK PANEL


P11274 | July 2024

ASSEMBLY DIAGRAM


Tools Required - Supplied



Parts




1




REMOVE TOP PANEL ASSEMBLIES


2




3



4



5



GARMIN

6

D X1 PLUG POWER FOR SCREEN INTO THE AVAILABLE POWER SOCKET.

SIT MEDIA PLAYER INTO CTU BASE TOWARD THE BACK
PLUG HDMI LEAD FROM SCREEN INTO AVAILABLE HDMI SLOT.

7

MEDIA PLAYER PSU **MEDIA PLAYER**

MEDIA PSU SHOULD BE LOCATED IN THE LEFT HAND CTU. FEED THE CABLE THROUGH THE GROMMET IN THE SIDES A PLUG INTO THE MEDIA PLAYER.

8

E X1 **H X4** **I X2**

10


D X1 CONNECT MEDIA PLAYER TO PCB BOARD VIA USB CABLE.

C X1

Do not use OTG port.

11

PLUG MOLEX CABLES INTO BOARD
REFERENCE THE PRODUCT LAYOUT
GUIDE AND MATCH THE NUMBERS TO
THE NUMBERS ON THE BOARD




12


E X1

H X4


I X2



10




11




USE THE KEY TO SECURE THE
TOP PANEL ASSEMBLIES INTO
THE CTU'S

12




REPLACE THE LENS, TICKETS
AND METAL PLATE

13



GARMIN

14



15

