



ASSEMBLY GUIDE


TOOLS REQUIRED – SUPPLIED




1




2




3




4




5



6




7




8

BLANK TOP SURFACE FOR PRODUCT
PLACEMENT, CUTOUPS OR
MOUNTING HOLE TO BE MADE ON
INSTALLATION OF CHOSEN
PRODUCTS




TEMPLATES SUPPLIED WITH
PRODUCT BOX OR ONLINE GARMIN
WEBSITE

EXAMPLE ABOVE




MAX 3 PRODUCT


9



10



11




12



PRODUCT


UNIT MUST BE DISCONNECTED
FROM POWER AND UNPLUG
BEFORE WIRING UP 12V POWER
SUPPLIES FROM PRODUCT TO
TERMINALS



14

(E) X1

Graphics Not
Supplied – to
be ordered
separately



14

